

Develop an python code

TEAM ID	PNT2022TMID46814
PROJECT NAME	Child safety monitoring and notification system

Temperature and Humidity sensor code:

"""

'temp_humidity.py'

=====

Example of sending analog sensor

values to an Adafruit IO feed.

Author(s): Brent Rubell

Tutorial Link: Tutorial Link: <https://learn.adafruit.com/adafruit-io-basics-temperature-and-humidity>

Dependencies:

- Adafruit IO Python Client

(<https://github.com/adafruit/io-client-python>)

- Adafruit_Python_DHT

(https://github.com/adafruit/Adafruit_Python_DHT)

"""

import standard python modules.

import time

import adafruit dht library.

import Adafruit_DHT

import Adafruit IO REST client.

from Adafruit_IO import Client, Feed

```
# Delay in-between sensor readings, in seconds.
DHT_READ_TIMEOUT = 5

# Pin connected to DHT22 data pin
DHT_DATA_PIN = 26

# Set to your Adafruit IO key.
# Remember, your key is a secret,
# so make sure not to publish it when you publish this code!
ADAFRUIT_IO_KEY = 'YOUR_AIO_KEY'

# Set to your Adafruit IO username.
# (go to https://accounts.adafruit.com to find your username).
ADAFRUIT_IO_USERNAME = 'YOUR_AIO_USERNAME'

# Create an instance of the REST client.
aio = Client(ADAFRUIT_IO_USERNAME, ADAFRUIT_IO_KEY)

# Set up Adafruit IO Feeds.
temperature_feed = aio.feeds('temperature')
humidity_feed = aio.feeds('humidity')

# Set up DHT22 Sensor.
dht22_sensor = Adafruit_DHT.DHT22

while True:
    humidity, temperature = Adafruit_DHT.read_retry(dht22_sensor, DHT_DATA_PIN)
    if humidity is not None and temperature is not None:
        print("Temp={0:0.1f}*C Humidity={1:0.1f}%".format(temperature, humidity))
```

```

# Send humidity and temperature feeds to Adafruit IO

temperature = '%.2f%(temperature)

humidity = '%.2f%(humidity)

aio.send(temperature_feed.key, str(temperature))

aio.send(humidity_feed.key, str(humidity))

else:

    print('Failed to get DHT22 Reading, trying again in ', DHT_READ_TIMEOUT,
'seconds')

# Timeout to avoid flooding Adafruit IO

time.sleep(DHT_READ_TIMEOUT)

```

Panic button specs setup:

```

#
# spec file for package Panic
#
# Copyright (c) 2016 SUSE LINUX Products GmbH, Nuernberg, Germany.
#
# All modifications and additions to the file contributed by third parties
# remain the property of their copyright owners, unless otherwise agreed
# upon. The license for this file, and modifications and additions to the
# file, is the same license as for the pristine package itself (unless the
# license for the pristine package is not an Open Source License, in which
# case the license is the MIT License). An "Open Source License" is a
# license that conforms to the Open Source Definition (Version 1.9)
# published by the Open Source Initiative.

# Please submit bugfixes or comments via http://bugs.opensuse.org/
#

%define _modname panic

Name:          Panic
Version:       5.5
Release:       0
License:       GPL-3.0+
Summary:       Alarm System toolkit
Url:           http://www.tango-controls.org/community/projects/panic/
Group:         Productivity/Scientific/Other
Source:        %{_modname}-%{version}.tar.gz
BuildRoot:     %{_tmppath}/%{name}-%{version}-build
BuildArch:     noarch

BuildRequires: python-devel
BuildRequires: python-setuptools

Requires:      python < 3
Requires:      python-numpy

```

Requires: python-taurus
Requires: python-pytango
Requires: python-fandango

%description

PANIC Alarm System is a set of tools (api, Tango device server, user interface) that provides:
Periodic evaluation of a set of conditions.
Notification (email, sms, pop-up, speakers)
Keep a log of what happened. (files, Tango Snapshots)
Taking automated actions (Tango commands / attributes)
Tools for configuration/visualization.

=====
python-panic
=====

%package -n python-panic

Summary: Alarm System toolkit. Python module

Group: Development/Languages/Python

%description -n python-panic

This package provides the "panic" python module from the PANIC Alarm System toolkit

=====
tangods-pyalarm
=====

%package -n tangods-pyalarm

Summary: Alarm System toolkit. PyAlarm Tango Device Server

Group: Development/Libraries

Requires: python-panic

#TODO: we should find a better group for DSs

%description -n tangods-pyalarm

This package provides the PyAlarm Tango Device Server from the PANIC Alarm System toolkit

%prep

%setup -n % {_modname} -% {version}

%build

%install

python setup.py install --prefix=% {_prefix} --root=% {buildroot}

%files -n python-panic

%defattr(-,root,root)

%exclude % {python_sitelib}/% {_modname}/ds

% {python_sitelib}

```
%files -n tangods-pyalarm
%defattr(-,root,root)
% {python_sitelib}/% {_modname}/ds
% {_bindir}/*
```

Panic button code:

```
#!/bin/sh

PANIC=$(python -c "import imp;print(imp.find_module('panic')[1])")

#PANIC_DEFAULT="--filter=!building"

HASSCREEN=$(which screen 2>/dev/null)
CMD="python $PANIC/gui/gui.py $PANIC_DEFAULT"

if [ "$( echo $1 | grep '\?\\-h' )" ] ; then
    echo "Usage:"
    echo "    > panic [-?] [-v/--attach] [--filter=...]"
    echo ""
    echo "Console output will be disabled unless attach/v options are passed"
    echo "SCREEN is used as default shell if present"
    echo ""
else
    echo "Launching panic-gui ..."
    if [ "$*" ] && [ "$( echo "$*" | grep '\-v' )" ] ; then
        echo "raw"
        CMD=${CMD}

    elif [ "$*" ] && [ "$( echo "$*" | grep 'attach' )" ] ; then
        echo "screen"
        if [ "${HASSCREEN}" ] ; then
            CMD="screen -S panic-gui ${CMD}"
        fi
    else
        echo "run detached"
        if [ "${HASSCREEN}" ] ; then
            CMD="screen -dm -S panic-gui ${CMD}"
        else
            CMD="${CMD} > /dev/null"
        fi
    fi
    echo $CMD $*
    $CMD $*
fi
```

Pressure sensor:

```
import serial, time

import RPi.GPIO as GPIO
```

```

import re

import smtplib,ssl

from email.mime.multipart import MIMEMultipart
from email.mime.base import MIMEBase
from email.mime.text import MIMEText
from email.utils import formatdate
from email import encoders


bp = 2 // Bp sensor status pin

GPIO.setwarnings(False)

GPIO.setmode(GPIO.BCM)

GPIO.setup(bp,GPIO.IN)

ser = serial.Serial("/dev/ttyS0",9600)

ser.baudrate = serial.EIGHTBITS #number of bits per bytes

ser.parity = serial.PARITY_NONE #set parity check: no parity

ser.stopbits = serial.STOPBITS_ONE #number of stop bits

ser.timeout = 1      #non-block read

ser.xonxoff = False  #disable software flow control

ser.rtscts = False   #disable hardware (RTS/CTS) flow control

ser.dsrdtr = False   #disable hardware (DSR/DTR) flow control

file = open('sensor_readings.txt', 'w')

#file.write('time and date, systolic(b), diastolic(c),Pulse(d)\n')

file.write(' Your Blood Pressure Details Are As Follows\n')


def send_an_email_normal():

    toaddr = 'to@gmail.com'    # To id

    me = 'your email id'      # your id

    subject = "Normal Blood pressure"      # Subject

    msg = MIMEMultipart()

    msg['Subject'] = subject

```

```

msg['From'] = me
msg['To'] = toaddr
msg.preamble = "test "
#msg.attach(MIMEText(text))

part = MIMEBase('application', "octet-stream")
part.set_payload(open("sensor_readings.txt", "rb").read())
encoders.encode_base64(part)
part.add_header('Content-Disposition', 'attachment; filename="sensor_readings.txt") # File
name and format name
msg.attach(part)

try:
    s = smtplib.SMTP('smtp.gmail.com', 587) # Protocol
    s.ehlo()
    s.starttls()
    s.ehlo()
    s.login(user = 'mailto:xxxxx@gmail.com', password = 'your email password') # User id &
password
    #s.send_message(msg)
    s.sendmail(me, toaddr, msg.as_string())
    s.quit()
except:
    # print ("Error: unable to send email")
except SMTPException as error:
    print ("Error")          # Exception

def send_an_email_Hypotension():
    toaddr = 'to@gmail.com'   # To id
    me = 'mailto:your email id'    # your id
    subject = "Hypotension"      # Subject
    msg = MIMEMultipart()

```

```

msg['Subject'] = subject
msg['From'] = me
msg['To'] = toaddr
msg.preamble = "test "
#msg.attach(MIMEText(text))

part = MIMEBase('application', "octet-stream")
part.set_payload(open("sensor_readings.txt", "rb").read())
encoders.encode_base64(part)
part.add_header('Content-Disposition', 'attachment; filename="sensor_readings.txt"') # File
name and format name
msg.attach(part)

try:
    s = smtplib.SMTP('smtp.gmail.com', 587) # Protocol
    s.ehlo()
    s.starttls()
    s.ehlo()
    s.login(user = 'mailto:xxxxx@gmail.com', password = 'your email password') # User id &
password
    #s.send_message(msg)
    s.sendmail(me, toaddr, msg.as_string())
    s.quit()
except:
    # print ("Error: unable to send email")
except SMTPException as error:
    print ("Error")          # Exception

def send_an_email_prehypertension():
    toaddr = 'to@gmail.com'    # To id
    me = 'mailto:your email id'    # your id
    subject = "Prehypertension"    # Subject

```



```

msg = MIMEMultipart()
msg['Subject'] = subject
msg['From'] = me
msg['To'] = toaddr
msg.preamble = "test "
#msg.attach(MIMEText(text))

part = MIMEBase('application', "octet-stream")
part.set_payload(open("sensor_readings.txt", "rb").read())
encoders.encode_base64(part)
part.add_header('Content-Disposition', 'attachment; filename="sensor_readings.txt") # File
name and format name
msg.attach(part)

try:
    s = smtplib.SMTP('smtp.gmail.com', 587) # Protocol
    s.ehlo()
    s.starttls()
    s.ehlo()
    s.login(user = 'mailto:xxxxx@gmail.com', password = 'your email password') # User id &
password
    #s.send_message(msg)
    s.sendmail(me, toaddr, msg.as_string())
    s.quit()
except:
    # print ("Error: unable to send email")
except SMTPException as error:
    print ("Error")          # Exception

def send_an_email_stage1():
    toaddr = 'to@gmail.com'   # To id
    me = 'mailto:your email id'    # your id

```

```

subject = "Stage 1 Hypertension"          # Subject
msg = MIMEMultipart()
msg['Subject'] = subject
msg['From'] = me
msg['To'] = toaddr
msg.preamble = "test "
#msg.attach(MIMEText(text))

part = MIMEBase('application', "octet-stream")
part.set_payload(open("sensor_readings.txt", "rb").read())
encoders.encode_base64(part)
part.add_header('Content-Disposition', 'attachment; filename="sensor_readings.txt") # File
name and format name
msg.attach(part)

try:
    s = smtplib.SMTP('smtp.gmail.com', 587) # Protocol
    s.ehlo()
    s.starttls()
    s.ehlo()
    s.login(user = 'mailto:xxxxx@gmail.com', password = 'your email password') # User id &
password
    #s.send_message(msg)
    s.sendmail(me, toaddr, msg.as_string())
    s.quit()
except:
    # print ("Error: unable to send email")
except SMTPException as error:
    print ("Error")          # Exception

def send_an_email_stage2():
    toaddr = 'to@gmail.com'   # To id

```

```

me = 'mailto:your email id'      # your id
subject = "Stage 2 Hypertension"    # Subject
msg = MIMEMultipart()
msg['Subject'] = subject
msg['From'] = me
msg['To'] = toaddr
msg.preamble = "test "
#msg.attach(MIMEText(text))

part = MIMEBase('application', "octet-stream")
part.set_payload(open("sensor_readings.txt", "rb").read())
encoders.encode_base64(part)
part.add_header('Content-Disposition', 'attachment; filename="sensor_readings.txt") # File
name and format name
msg.attach(part)

try:
    s = smtplib.SMTP('smtp.gmail.com', 587) # Protocol
    s.ehlo()
    s.starttls()
    s.ehlo()

    s.login(user = 'mailto:xxxxx@gmail.com', password = 'your email password') # User id &
password
    #s.send_message(msg)
    s.sendmail(me, toaddr, msg.as_string())
    s.quit()
except:
    # print ("Error: unable to send email")
except SMTPException as error:
    print ("Error")          # Exception

def send_an_email_hypertensive():

```

```

toaddr = 'to@gmail.com'    # To id
me = 'mailto:your gmail id'    # your id
subject = "Hypertensive Crisis"    # Subject
msg = MIMEMultipart()
msg['Subject'] = subject
msg['From'] = me
msg['To'] = toaddr
msg.preamble = "test "
#msg.attach(MIMEText(text))

part = MIMEBase('application', "octet-stream")
part.set_payload(open("sensor_readings.txt", "rb").read())
encoders.encode_base64(part)
part.add_header('Content-Disposition', 'attachment; filename="sensor_readings.txt") # File
name and format name
msg.attach(part)

try:
    s = smtplib.SMTP('smtp.gmail.com', 587) # Protocol
    s.ehlo()
    s.starttls()
    s.ehlo()
    s.login(user = 'mailto:xxxxx@gmail.com', password = 'your email password') # User id &
password
    #s.send_message(msg)
    s.sendmail(me, toaddr, msg.as_string())
    s.quit()
except:
    # print ("Error: unable to send email")
except SMTPException as error:
    print ("Error")    # Exception

```

```

while True:

    response = ser.readline().decode('ASCII')

    x = len(response)# checking the available bytes in the serial data

    if x >= 10:

        print("systolic,diastolic,Pulse")

        print(response)

        y = response.split(',') #splitting the each bytes with comma

        print(y)

        z = re.findall('[0-9]+', response) # extracting each byte

        print(z)

        a = [z] # creating extracted each byte in a array

        b = int(z[0]) # first byte in a array (Systolic)

        c = int(z[1]) # second byte in a array (diastolic)

        d = int(z[2]) # third byte in a array (pulse)

        print("Systolic :", b)

        print("Diastolic :",c)

        print("Pulse:" , d)

        file.write(time.strftime('%H:%M:%S %d/%m/%Y') + ' Systolic:' + str(b) + ' Diastolic:' + str(c) + ' Pulse rate:' + str(d) + '\n')

        time.sleep(1)

        file.close()

        print("file written")

        if b < 90 and c < 60:

            print('Hypotension')

            send_an_email_Hypotension()

        if b > 120 and b < 139 and c > 80 and c < 90:

            print('Prehypertension')

            send_an_email_prehypertension()

        if b > 140 and b < 159 and c > 90 and c < 99:

```

```
print('stage 1 Hypertension')
```

```
send_an_email_stage1()
```

```
if b > 160 and b < 179 and c > 100 and c < 109:
```

```
    print('stage 2 Hypertension')
```

```
    send_an_email_stage2()
```

```
if b > 180 and c > 110:
```

```
    print('Hypertensive Crisis')
```

```
    send_an_email_hypertensive()
```

```
else:
```

```
    send_an_email_normal()
```

```
    print('sent_the_mail')
```